



Tag and probe tools for data driven corrections

Yuan Zhang

2024/10/16

O2 Analysis tutorial 4.0

Motivation

- ❑ MC simulation can not describe data well.




- ❑ Need data driven calibration.

- ❑ A lot of photon converted electrons in electrons sample
- ❑ To learn ITS-TPC matching efficiency, we need to exclude photon converted electrons without ITS cuts.



- ❑ Use Tag and Probe method

Tag and probe



$$\mathcal{B}(\pi^0 \rightarrow e^+ e^- \gamma(\gamma)) = 1.1836(6)\%$$

The lifetime is $8.5 \times 10^{-17}\text{s}$

- The tag and probe method involves selecting a clean sample of electrons from π^0 Dalitz decay.
- One of the electron (the **tag**) is well-identified.
- Another electrons (the **probe**) from same pair is used for the TPC and ITS matching efficiency study.
- The photon converted electrons need to be rejected.

Dalitz selection in O2Physics

```
o2-analysis-dq-table-reader -b --configuration json://configuration.json | \  
o2-analysis-dq-table-maker -b --configuration json://configuration.json | \  
o2-analysis-dq-dalitz-selection -b --configuration json://configuration.json | \  
o2-analysis-multiplicity-table -b --configuration json://configuration.json | \  
o2-analysis-pid-tof-full -b --configuration json://configuration.json | \  
o2-analysis-pid-tof-beta -b --configuration json://configuration.json | \  
o2-analysis-pid-tof-base -b --configuration json://configuration.json | \  
o2-analysis-ft0-corrected-table -b --configuration json://configuration.json | \  
o2-analysis-track-propagation -b --configuration json://configuration.json | \  
o2-analysis-trackselection -b --configuration json://configuration.json | \  
o2-analysis-pid-tpc -b --configuration json://configuration.json | \  
o2-analysis-event-selection -b --configuration json://configuration.json | \  
o2-analysis-timestamp -b --configuration json://configuration.json | \  
o2-analysis-pid-tpc-base -b --configuration json://configuration.json --aod-writer-json OutputDirector.json
```

- Run the table-maker and table-reader with dalitz-selection task.
- Save the derived table “DielectronsAll” in table-reader and do the tag-probe locally.

Dalitz selection in O2Physics

Dalitz-pairing:

```
"cfgDalitzTrackCuts": "Jpsi_TPCPost_calib_noITSCuts_debug4",  
"cfgDalitzPairCuts": "pairDalitz1",
```

Table-maker:

```
"cfgBarrelTrackCuts": "dalitzSelected1",  
"processBarrelOnlyWithDalitzBits": "false",  
"processBarrelWithDalitzEvent": "true",
```

- ❑ processBarrelOnlyWithDalitzBits: run table-maker with dalitz information
- ❑ processBarrelWithDalitzEvent: run table-maker with dalitz information and skip events without dalitz tracks

OutputDirector.json

```
{  
  "OutputDirector": {  
    "debug_mode": true,  
    "resfile": "A02D",  
    "OutputDescriptors": [  
      {  
        "table": "AOD/RTDIELECTRONALL/0"  
      }  
    ],  
    "ntfmerge": 1  
  }  
}
```

- ❑ Save DielectronsAll table to do tag and probe locally.

Dalitz selection

LHC22o pass4: 528021, 528026, 528036, 528094, 528097, 528105, 528107, 528109, 528231, 528232, 528233, 528263, 528266, 528292, 528294, 528316, 528319, 528328, 528329, 528330, 528332, 528336, 528347, 528359, 528379, 528381, 528386, 528448, 528451, 528461, 528463, 528530, 528531, 528534

Pair cut (default)

$$0 < m < 0.035 \text{ GeV}/c^2$$

Triangle cut (ψ_{pair} and $\Delta\phi$) (to reject photon conversion electron):

Reject pairs with $(\Delta\phi, \psi_{pair})$ in triangle (0, -0.8) (0, 0.8) (0.12, 0)

Track cut (default)

$$p_T > 1.0 \text{ GeV}/c, |\eta| < 0.9$$



$$\text{TPCncls} > 90, \text{TPCchi2} < 4$$

ITSRequirement: ITSMatch (tag)


$$-3 < \text{TPCnSigmaE} < 3$$

$$|\text{TPCnSigmaPi}| > 3$$

$$|\text{TPCnSigmaPr}| > 3$$



PID performance




- TPCnSigmaE distribution of tag and probe tracks.
- Electron purity is high after PID selections

Matching efficiency with different tag cuts

$$eff = \frac{N_{TPC+ITSall}^{probe}}{N_{TPC}^{probe}} \quad \text{ITSall: hit all 7 layers of ITS}$$

Tag ITS Requirement with the below:

1. NoITSRequire:
 - No ITS requirement
2. SPDFirst:
 - at least one hit on the inner most layer
3. SPDAny:
 - at least one hit on the first two layers
4. ITSMatch:
 - any hits on the ITS
5. ITSMatchDCA:
 - any hits on the ITS + DCA ($|xy| < 0.1 \text{ cm}$, $|z| < 0.15 \text{ cm}$)




- The matching efficiency of probe will increase if the tag is with a strict ITS requirement.
- The ITS-TPC matching efficiency decrease to very low in high p_T .




- Photon converted electrons contamination.

Check triangle cut in MC




➤ The ψ_{pair} and $\Delta\phi$ distribution are different between electron pairs from photon conversion and dalitz decay.

Check triangle cut in MC



- The ψ_{pair} distributions before and after triangle cut are shown.
- Large fraction of photon converted electrons are rejected ($> 90\%$ in middle and high p_T), but still a lot of leftovers

Check using MC



- Electron pairs from pi0 decay are selected.
 - Apply tag cut on one leg and use the other as probe to check ITS-TPC matching efficiency.
- The efficiency of probe leg are similar with all electrons from pi0.
- Slight correlation between matching efficiency of probe with tag cuts.
 - Further checks needed.

Select pure electrons using J/ψ

LHC22o_pass4_minBias_medium:

526641, 526964, 527041, 527240

Pair cut (default)

$$2.84 < m < 3.2 \text{ GeV}/c^2$$

Track cut (default)

$$p_T > 1.0 \text{ GeV}/c, |\eta| < 0.9$$

$$\text{TPCncls} > 90, \text{TPCchi2} < 4$$

ITSRequirement: ITSMatch (Tag)

$$-3 < \text{TPCnSigmaE} < 3$$

$$|\text{TPCnSigmaPi}| > 3$$

$$|\text{TPCnSigmaPr}| > 3$$

Prefilter cut:







$$p_T > 0.15 \text{ GeV}/c, |\eta| < 0.9$$

$$\text{TPCncls} > 70, \text{TPCchi2} < 4$$



$$|\text{TPCnSigmaE}| < 3$$

$$\text{Exclude } m_{ee} < 0.35 \text{ GeV}/c^2$$

➤ The S/B is ~ 0.35 in low pT, but can reach to ~ 2.43 in high pT.




ITS-TPC matching efficiency using eFromJ/ ψ



- ITS-TPC matching efficiency of probe e from unlike-sign pair is close to that of inclusive charged tracks in high p_T .
- Efficiency is low in low p_T because of the low S/B.


ITS-TPC matching efficiency with different tag cuts



- ITS requirement on the tag will not influence the matching efficiency of the probe too much.



Tag and probe using J/ψ counts

- To avoid the influence of photon converted electrons, ITS-TPC matching efficiency can also be calculated by directly using tag and probe method to J/ψ counts.



- Raw counts of J/ψ with probe leg after ITS cut are used as nominator.
- Raw counts of J/ψ with probe leg without ITS requirement are used as denominator


Tag and probe using J/ψ counts



$$eff = \frac{N_{ITSall}^{Jpsi}}{N_{Jpsi}}$$

- ITS-TPC matching efficiency can be calculated by raw counts of J/ψ by changing the ITS requirement on one leg.
- Will be influenced by the systematic uncertainty of signal extraction.

ITS-TPC matching efficiency



- ITS requirement on the tag will not influence the matching efficiency of the probe too much.

Summary

- The ITS-TPC matching efficiency is measured using tag and probe method.
 1. Using the dalitz selection to select pure primary electrons.
 - ❑ Some photon converted electrons left.
 2. Using J/ψ signal to select primary electrons.
 - ❑ Efficiency are similar with inclusive charged tracks in high p_T .
 - ❑ Efficiency is lower in low p_T because of the low S/B .
 3. Using tag and probe to J/ψ directly.
 - ❑ Get similar efficiency with inclusive charged tracks.
 - ❑ Will be influenced by the systematic uncertainty from signal extraction.

Back up

Code of DalitzSelection

1. runTrackSelection<gkTrackFillMap>(groupedFilteredTracks);

```
for (auto& track : tracksBarrel) {
    uint8_t filterMap = uint8_t(0);
    VarManager::FillTrack<TTrackFillMap>(track);
    int i = 0;
    for (auto cut = fTrackCuts.begin(); cut != fTrackCuts.end(); ++cut, ++i) {
        if ((*cut).IsSelected(VarManager::fgValues)) {
            filterMap |= (uint8_t(1) << i);
        }
    }
    if (filterMap) {
        fTrackmap[track.globalIndex()] = filterMap;
    }
} // end loop over tracks
```

Code of DalitzSelection

2. `runDalitzPairing<pairType, gkTrackFillMap>(groupedFilteredTracks, groupedFilteredTracks);`

```
int icut = 0;
auto trackCut = fTrackCuts.begin();
for (auto pairCut = fPairCuts.begin(); pairCut != fPairCuts.end(); pairCut++, trackCut++, icut++) {
    if (!(twoTracksFilterMap & (uint8_t(1) << icut))) {
        continue;
    }
    if ((*pairCut).IsSelected(VarManager::fgValues)) {
        fDalitzmap[track1.globalIndex()] |= (uint8_t(1) << icut);
        fDalitzmap[track2.globalIndex()] |= (uint8_t(1) << icut);
        if (fQA) {
            fHistMan->FillHistClass(Form("Pair_%s_%s", (*trackCut).GetName(), (*pairCut).GetName()), VarManager::fgValues);
        }
    }
}
```

3. `for (auto& track : tracks) { // Fill dalitz bits`
 `dalitzbits(fDalitzmap[track.globalIndex()]);`
}