

# **O2DQ Tutorials: Global muons**

16/10/2024

**Emilie Barreau** 

### Global muon refit at analysis level





Option in O2-DQ to recompute track parameters instead of using reco track fitting:

$$p_x = p_{MCH} \sin(\theta_{MFT}) \cos(\phi_{MFT})$$

$$p_y = p_{MCH} \sin(\theta_{MFT}) \sin(\phi_{MFT})$$

$$p_z = p_{MCH} \cos(\theta_{MFT})$$






#### Secondary vertexing



- Global muon tracks contain MFT information and can be used for secondary vertexing
- Two different secondary vertexing algorithm are currently implemented in DQ:
  - DCAFitter




### TableMaker\_withAssoc config: global MUON




In file configs/configTableMakerData\_withAssoc\_globalmuon.json

When global muon tracks are kept, the corresponding MFT and standalone muons used for the matching are also kept in the reduced AOD tables, even when requiring only global muon tracks (e.g. w/ "matchedQualityCuts" or "matchedGlobal")



# TableMaker\_withAssoc config: global MUON





# TableReader\_withAssoc config: global MUON

"processDummy": "false"



```
"analysis-same-event-pairing": {
    "cfgTrackCuts": "jpsiO2MCdebugCuts2",
                                                            Now require only global muons in the output
    "cfgMuonCuts": "matchedGlobal",
    "cfqPairCuts": "",
"cfqAddSEPHistogram": "dimuon,barrel,vertexing",
  fgFlatTables": "true".
                                                            False: use DCAFitter, True: use Kalman Filter
  qUseKFVertexing": "false",
 "processAllSkimmed": "false",
"processBarrelOnlySkimmed": "false",
"processBarrelOnlyWithCollSkimmed": "false",
"processBarrelOnlySkimmedNoCov": "false",
"processMuonOnlySkimmed": "true",
"processMixingAllSkimmed": "false",
"processMixingBarrelSkimmed": "false",
```

### **Hyperloop operations**



Wagon	LHC23_pass4	LHC24e5	Last run			
fwdtrack-collision-associator	×	×		VS	#	
TableMaker_globalmuon_pp	×	×		VS	\$	
TableMaker_muon_pp	×	×		VS	#	
TableReader_globalmuon_pp 👛	✓ *	✓ *		VS	#	
TableReader_muon_pp 👛	<b>☑</b> *	✓ *		VS	#	8

#### Run TableMaker\_withAssoc



In the O2DQTutorials/:

- Enter local O2Physics environment (ideally not older than 12<sup>th</sup> October),
   or on lxplus: /cvmfs/alice.cern.ch/bin/alienv enter VO ALICE@O2sim::v20241014-1
- python3 O2DQworkflows/runTableMaker\_withAssoc.py configs/configTableMakerData\_withAssoc\_globalmuon.json -runData
- o2-analysis-dq-table-reader-with-assoc -b --configuration
  json://configs/configAnalysisData\_withAssoc\_globalmuon.json --aod-file
  reducedAod.root (--aod-writer-json configs/writerTableReaderFlatTable.json)